dti™ DIAMOND GUARD FILTER INSTALLATION GUIDE

QUESTIONS ABOUT INSTALLING YOUR FILTER?

CALL: 360.866.1337

EMAIL: info@dtiinside.com

dti[™]'s Diamond Guard Filters and Adapters allow for ease of installation in any waterjet system's 1/4" or 3/8" high pressure lines. The DG Filter is installed as close to the waterjet orifice assembly as possible, with the most common location being in the HP fitting at the on/off valve assembly. The three following examples give instructions on how to install your DG filter and protect your diamond, tetraCORE™ and ruby orifices.



EXAMPLE 1

When the $\frac{1}{4}$ " high pressure line runs directly into a mounting block, which then goes into a valve body, this is where the $\frac{3}{8}$ " Male to $\frac{1}{4}$ " Female adapter is located (MA-FIL-07).

EXAMPLE 2

When the high pressure line is connected directly into the valve body, this is where the 3/8" Female and 3/8" Male adapter is located (MA-FIL-02).



When there is no standard fitting that goes directly into the HP valve body, a 3/8" line goes directly to the cutting head from a 3/8" HP elbow and the whip line is connected at the elbow. A $\frac{1}{4}$ " Female by 3/8" Male adapter is inserted where the whip connects to the elbow (MA-FIL-07).

THIS FILTER IS ALSO COMMONLY KNOWN AS:

Witch Hat Filter Diamond Guard Filter/DG Filter

Cone Filter Last Chance Filter

Thimble Filter